

# **SUPER BRAIN 819**

## **AC/DC DELTA PEAK QUICK CHARGER**

### **Caution**

1. This charger is designed for 6-7 cells (7.2-8.4 volt) NiCd battery. Never try to charge any battery other than a 6 or 7 cell-NiCd battery with this charger.
2. Never use AC and DC input at the same time.
3. Do not use the charger with the car's engine running.
4. Never leave the charger unattended while charging a battery; the ultimate safety device is your vigilance. Disconnect the battery if it becomes hot.
5. Do not allow moisture to enter the charger.
6. Always unplug the charger from outlet when it is not in use.

### **Operation**

Plug the AC cord into AC outlet, or if you use DC input, connect the red clamp to a 12V car battery's positive terminal and the black clamp to the negative terminal. The pilot light will blink.

Plug in the battery. The charger will automatically start to charge the battery. The pilot light will stay on to indicate the fast charging. When the fast charging is complete, the pilot light will blink and you can charge another battery. Otherwise it will trickle charge for 90 minutes. After that, the charger will shut down completely.

### **Return Procedure**

If it should be necessary to return your RB819 for service, please include a letter that is printed clearly with your name, address, a daytime telephone number, and a detailed description of the problem you are experiencing.

Send to:       Model Rectifier Corporation  
                  Attn: Parts & Service  
                  80 Newfield Avenue  
                  Edison, NJ 08837-3817

© 1999 Model Rectifier Corporation  
80 Newfield Ave  
Edison, NJ 08837-3817  
Telephone 732-225-6360

Printed in China  
INS-2263